

**RS ME**  
 PRE POČETKA MONTIRANJA OBAVEZNO  
 PROČITAJTE UPUSTVO ZA MONTAŽU

**UK**  
 BEFORE STARTING, REFER TO THE  
 ASSEMBLING ADVICE IN ANNEX







**DE AT CH**  
 VOR DER MONTAGE BITTE BEILIEGENDE  
 ANWEISUNGEN LESEN

**FR CH**  
 AVANT DE COMMENCER L'ASSEMBLAGE,  
 ASSUREZ-VOUS DE LIRE LES INSTRUCTIONS  
 D'ASSEMBLAGE

**SL**  
 PRED PRIČETKOM MONTAŽE OBEVNO  
 PREBERITE NAVODILA ZA MONTAŽO

**HR**  
 PRIJE POČETKA MONTAŽE OBAVEZNO  
 PROČITATI UPUTE ZA MONTAŽU

**BIH**  
 PRIJE POČETKA MONTIRANJA OBAVEZNO  
 PROČITAJTE UPUSTVO ZA MONTAŽU

 Tockic x4	 DIN7505 4x25 x8	 x 2	 5 min
 DIN7505 4x30 x4	 H3/F13 x4		