

**RS ME**

PRE POČETKA MONTIRANJA OBAVEZNO  
PROČITAJTE UPUSTVO ZA MONTAŽU

**UK**

BEFORE STARTING, REFER TO THE  
ASSEMBLING ADVICE IN ANNEX

**DE AT CH**

VOR DER MONTAGE BITTE BEILIEGENDE  
ANWEISUNGEN LESEN

**FR CH**

AVANT DE COMMENCER L'ASSEMBLAGE,  
ASSUREZ-VOUS DE LIRE LES INSTRUCTIONS  
D'ASSEMBLAGE

**SL**

PRED PRIČETKOM MONTAŽE OBEVNO  
PREBERITE NAVODILA ZA MONTAŽO

**HR**

PRIJE POČETKA MONTAŽE OBAVEZNO  
PROČITATI UPUTE ZA MONTAŽU

**BIH**

PRIJE POČETKA MONTIRANJA OBAVEZNO  
PROČITAJTE UPUSTVO ZA MONTAŽU



Tockić x4



DIN7505 4x25 x8



x 2



5 min



DIN7505 4x30 x4



H3/F13 x4