Assembly Instruction:

- 1- Turn over the back of the chair you bought.
- 2- Turn over the metal leg that comes out of the box as shown in the picture below. Make sure to put the foot straight.
- 3- You can install the product with drill or cross headed screwdriver.
- 4- Screw the biggest screw (5,50) coming out of the box to the back side.
- 5- Screw the medium screw (5,40) coming out of the box to the back side.
- 6- Screw the smallest screw (4,20) coming out of the box to the back side.
- 7- Our company controls the foot balances, but there may be deteriorations due to careless transportation of the cargo companies. If there is a problem with the balance of the feet, you can regain balance by stretching the feet that are fully on the ground to the outside.

