

ASSEMBLY INSTRUCTION

330-00021

Before you begin, please follow Assembly Instruction carefully. Follow them step by step.

<p>STEP 1</p> <p>(A) M6 X 20MM JCBC SCREW - 4 PCS</p> <p>(D) M4 ALLEN KEY (BALL TYPE) - 1 PC</p>	<p>STEP 2</p> <p>(A) M6 X 20MM JCBC SCREW - 4 PCS</p> <p>(D) M4 ALLEN KEY (BALL TYPE) - 1 PC</p>
<p>STEP 3</p> <p>(A) M6 X 20MM JCBC SCREW - 8 PCS</p> <p>(D) M4 ALLEN KEY (BALL TYPE) - 1 PC</p>	<p>STEP 4</p> <p>(B) M6 X 65MM JCBC SCREW - 4 PCS</p> <p>(D) M4 ALLEN KEY (BALL TYPE) - 1 PC</p>

ASSEMBLY INSTRUCTION

330-00021

Before you begin, please follow Assembly Instruction carefully. Follow them step by step.

<p>STEP 5</p> <p>(B) M6 X 65MM JCBC SCREW - 4 PCS</p> <p>(C) M6 HEX NUTS - 4 PCS</p> <p>(D) M4 ALLEN KEY (BALL TYPE) - 1 PC</p>	<p>PART LIST</p>	
<p>FULL SETUP</p>	<p>1) HEAD POST X 2 PCS</p>	<p>4) CENTER RAIL X 2 PCS</p>
<p>2) FOOT POST X 2 PCS</p>	<p>5) SIDE LEGS X 2 PCS</p>	<p>6) CENTER LEGS X 4 PCS</p>
<p>3) HEADBOARD/FOOTBOARD X 2 PCS</p>	<p>7) METAL BED BASE X 2 SETS</p>	
<p>HARDWARE LIST</p>		
<p>(A) M6 X 20MM JCBC SCREW - 16 PCS</p>	<p>(C) M6 HEX NUTS X 4 PCS</p>	
<p>(B) M6 X 65MM JCBC SCREW - 8 PCS</p>	<p>(D) M4 ALLEN KEY (BALL TYPE) X 1 PC</p>	