


ASSEMBLING INSTRUCTION

001-000011

 Ax1

 Bx1


 Cx1

 Dx1


 Ex1

 Fx4


1



2



3



4

