












Ax1 	Jx1 
Bx5 	Kx1 
Cx1 	Lx14  M8x25mm
Dx1 	Mx2  M5x10mm
Ex1(L)x1(R) 	Nx14 
Fx1 	Ox14 
Gx1 	Px4 
Hx1 	Qx1 
Ix1(L)x1(R)  IL  IR	



SPARE SCREWS

 x1
  x1
  x1
  x1
  x1

M8x25mm M5x10mm