


120-000595



INSTALLATION

Screw the fasteners with 3 screws each with the help of a screwdriver or drill by bringing them to the appropriate range.

