


ASSEMBLY INSTRUCTION
MODEL : / BOOKCASE


123-000240

Before you begin, please follow assembly instruction carefully.
 Then follow them step by step.


STEP 1




STEP 2




STEP 3




STEP 4



STEP 5



STEP 6



HARDWARE LIST

NO	DESCRIPTION		QTY
I	JCBCW SCREW M6.3 x 50		56pcs
II	M4 ALLEN KEY		1pc

III STICKER


IV	PVC NAIL WITH PIN		6pcs
V	WALL PLUG		1pc
VI	L-BRACKET		1pc

VII M4 x 16 CHIPBOARD SCREW

VIII	M4 x 38 CHIPBOARD SCREW		1pc

CAUTION:


To clean use soft, dry cloth. Do not use detergent or chemicals
Avoid contact with water and direct sunlight.
To be assembled on a soft, dry, clean and smooth surface.



COMPLETE SET

ORDERING REPAIR PARTS

In order to obtain smooth and rapid service when ordering repair parts, please give full attention to the following of PART NUMBER.



NO	DESCRIPTION	QTY
A	LEFT SIDE	01
B	LOWER SHELF	01
C	SHELF	05
D	CENTRE VERTICAL	05

NO	DESCRIPTION	QTY
E	SHELF	05
F	RIGHT SIDE	01
G	BACK	01