









197-000185



Instruction Manual





A01  *14 mm 14x	A02  *5x45 mm 10x	A03  *8x30 mm 10x	A10  14x
A60  2x			






Important information
Read carefully.
Keep this information for further reference.

GB WARNING




Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.

Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer.





8.






1.



2.



3.



5.

