













197-000186



Instruction Manual





A01  14x *14 mm	A02  10x *5x45 mm	A03  10x *8x30 mm	A10  14x
A60  2x			






Important information
 Read carefully.
 Keep this information for further reference.

GB WARNING




Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall.

Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer.





8.






1.



2.



3.



5.

