



ASSEMBLY INSTRUCTION

262-000018


1




2



3



4



Ax1




Bx1




Cx1



Dx1



Ex1




Fx4



Gx4



Hx4



Ix4



Jx1

