



ASSEMBLY INSTRUCTION

262-000022




Ax1			Bx1		
Cx1			Dx1		
Ex4			Fx4		
Hx1			Gx4		
Ix4					


1



2



3



4

