



318-000001




Assembling instruction



EN.Follow the manufacturer's assembly instructions, otherwise danger may occur.










- EN -

Furniture containing wood-based panels (particle board, fibreboard, plywood etc.) may emit into indoor air inconsiderable amounts of substances used in the production processes. The level of this emission is examined and it meets the applicable standards. After assembling the furniture, it is advised to regularly ventilate the room where the furniture stands, which should last about four weeks or until the smell is eliminated.



Service






| CODE | DIMENSIONS | Colli -0001 | Colli -0002 | Colli -0003 |
|---------------|-------------------|------------------------|------------------------|------------------------|
| 021523 | 1518x620x2 | 1 | | |
| 021582 | 1982x818x2 | | | 1 |
| 144658 | 1956x587x15 | | 1 | |
| 144659 | 1956x587x15 | | 1 | |
| 144660 | 1956x587x15 | | 1 | |
| 337230 | 1444x588x15 | 2 | | |
| 337231 | 797x508x15 | 1 | | |
| 337232 | 600x508x15 | 1 | | |
| 337233 | 600x586x15 | 1 | | |
| 42102 | 598x500x15 | 1 | | |
| 633674 | 1950x394x15 | | | 2 |
| 633675 | 1484x594x15 | 1 | | |
| 74806 | 594x221x15 | | | 2 |
| 82035L | 452x140x12 | | | 2 |
| 82035P | 452x140x12 | | | 2 |
| 82338T | 568x140x12 | | | 2 |
| 90866 | 579x448x2 | | 2 | |

| | | | |
|--|---|--|--|
| 36x S70969 Ø8x28  | 4x S39450  | 28x S30211  | 4x S39449 Ø12x10  |
| 24x S30212 Ø15x12  | 5x S30106 Ø3.5x15  | 10x S30157 Ø4x30  | 4x S30158 Ø3x12  |
| 6x S34654 Ø4x24  | 4x S31298-14 Ø4x14  | 8x S30102 Ø6,3x13  | 4x S30142 M4x9  |
| 60x S31299 Ø1,6x30  | 2x S33396  | 12x S30312  | 6x S30544  |
| 4x S30337-23  | 3x S36106  | 1x S30577  | 1x S20553N  |
| 2x S34676-15 L=450  | 2x S36628 Ø10x50, Ø5x60  | | |
| 2x S32892-N  | 5x S33652 L - 370/(320)  | | |
| 1x S36124 L=791  | 4x S36067 310x27mm  | | |
| 9x S3-S34611  | | | |




1





2




3





4




337232





337233





144659




5






6







7





8




9




10




11




144658






12 x1





13




14 x1





15



16





17





a = b

12x
S31299


12x
S30312



48x
S31299



18




1x
S36124







max
25 kg

1x
S30106



1x
S36106




19







-EN- Before suspending or fixing furniture to the wall (in order to prevent falling over), check the type and strength of the wall. Select wall plugs and screws appropriate for the given type of the wall. In the case of doubts, contact a specialist. The installation must be performed by a competent person. **WARNING!!! If the raw/plugs with screws are attached to the product, then they are intended only for wall.**

20



21









633674

633674


6x
S3-S34611







22





3x
S3-S34611







1x
S33652

2x
S30157


25 x2




26 x2







27 x2



28 x2




29 x2







1x
S34676-15


2x
S30158





30



31





- EN- GUIDELINES FOR FURNITURE CARE

Please follow the below specified remarks in order to properly take care of your furniture:

A clean dry soft fabric must be used for cleaning. If the furniture requires thorough cleaning, then you can slightly moistened it with water or cleaning agent designed for furniture cleaning, and subsequently the cleaned elements must be wiped until they're dry. Metal and glass parts must be cleaned using commercially available cleaning agents designed for cleaning of this type of materials, in accordance with the included instructions.

Do not use corrosive agents, scouring agents and other agents if their intended use is unknown.

The cleaning agents must have clear marking that they are intended for cleaning furniture.

WARNING!!! High gloss elements, from which the protective foil was removed, may be cleaned and used only after 72 hours.

