
## **Functional Instructions**








Press this button once in 10 seconds after the lamp has been powered on

After the lamp is electrified, press the SETUP key (code key)on the remote control quickly in 10 seconds. The light flashes indicate the code is successful. Otherwise, turn off the total power supply of the lamp, and then re-operate this step until the light flashes and the alignment is successful.



Long press or click this button, brightness will reduce

Long press this button, the color temperature increases, and the lights color turns white.

Long press this button, the color temperature drops, and the lights color turns warm.

Press this button,the lamp turns into warm light (3300K)



Click this button to switch the color temperature between white light,warm light and neutral light.

Press this button to switch the lamp between full power and half power,and the color temperature of the lamp is neutral light.