















420-000003



INSTALLATION STEP DIAGRAM

PARTES

a BACK 	b SEAT 	c ARMRESTS  L R	d MECHANISM 	e HEADREST 	f BASE 	g GAS LIFT 	h CASTER  5pcs
i WRENCH  M6X6mm	j 8*32mm  8pcs	k 6*20mm  6pcs	L DECORATIVE COVER 	M ARMREST COVER 			

INSTRUCCIONES

1




Diagram showing the gas lift (g) being inserted into the base (f) and secured with casters (h).

2




Diagram showing the seat (b) being attached to the mechanism (d) using screws (k).

3




Diagram showing the backrest (a) being attached to the seat (b) using screws (j).

4

Don't tighten the screws fully, remain 3%




Diagram showing the armrests (c) being attached to the seat (b) using screws (j) and decorative covers (M).

5




Diagram showing the headrest (e) being attached to the backrest (a) using screws (k).

6




Diagram showing decorative covers (L) being attached to the headrest (e).